


The **J-CLASS** collection

# SERPENT CALENDAR

How to use your watch



## WATCH SETTING

THREE-position crown

- 1. Neutral and winding position**  
Allows the user to manually wind their watch by turning the crown upwards.
- 2. Quick setting position for the date**  
Allows the user to change the date by simply turning the crown downwards.
- 3. Time setting position**  
Allows the user to set the time by turning the crown and turning the hands to the right time.



**SPEAKE-MARIN**

## CAUTION

The owner of the watch must under no circumstances, use the system quick change date system (crown in position 2) between 20h00 and 2h00.

If the user does not know if the watch is in the AM or the PM mode, they should set the hands so that the hour displayed is 2h00 (crown in position 3), and once the date is changed, they can modify it without risk of damaging the movement or altering its accuracy.

When you set the time during an afternoon, remember to do this after 12h00 to be in the right AM/PM sequence.

After having carried out this operation, put the crown back in position 1, turn it downwards once and check that it turns freely.

Every time you manipulate the crown, change the time or the date, remember to return the crown to position 1.

## WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.